

For information regarding the equipment listed below, refer to the “Navigation System Owner’s Manual”.

- Navigation system
- Audio/video system

1

Before driving

1-1. Hybrid system	
Hybrid system.....	36
1-2. Key information	
Keys	49
1-3. Opening, closing and locking the doors and trunk	
Smart access system with push-button start	54
Wireless remote control.....	67
Doors.....	70
Trunk.....	75
1-4. Adjustable components (seats, mirrors, steering wheel)	
Front seats.....	82
Power rear seat.....	88
Driving position memory	98
Rear seat position memory	104
Head restraints.....	106
Seat belts	109
Steering wheel.....	116
Anti-glare inside rear view mirror	117
Outside rear view mirrors	119
1-5. Opening and closing the windows and moon roof	
Power windows.....	121
Moon roof	124
1-6. Refueling	
Opening the fuel tank cap.....	128
1-7. Theft deterrent system	
Immobilizer system	133
Alarm.....	135
1-8. Safety information	
Correct driving posture	138
SRS airbags	140
Front passenger occupant classification system.....	153
Child restraint systems	158
Installing child restraints	163

2 When driving

2-1. Driving procedures

Driving the vehicle.....	174
Power (ignition) switch.....	184
EV drive mode.....	188
Transmission.....	190
Turn signal lever.....	195
Parking brake.....	196
Brake Hold.....	199
Horn.....	201

2-2. Instrument cluster

Gauges and meters.....	202
Indicators and warning lights.....	207
Multi-information display.....	211

2-3. Operating the lights and windshield wipers

Headlight switch.....	216
Automatic High Beam.....	220
Fog light switch.....	226
Windshield wipers and washer.....	228
Headlight cleaner switch.....	232

2-4. Using other driving systems

Cruise control.....	233
Dynamic radar cruise control.....	237
Intuitive parking assist.....	250
LKA (Lane-Keeping Assist).....	258
Electronically modulated air suspension.....	265
Advanced parking guidance system.....	267
Driving assist systems.....	308
Pre-Collision System.....	315

2-5. Driving information

Cargo and luggage.....	326
Vehicle load limits.....	329
Winter driving tips.....	331
Trailer towing.....	335
Dinghy towing.....	336

3 Interior features

3-1. Using the touch screen

Touch screen	338
Set up screen	339
Information screen	340

3-2. Using the air conditioning system and defogger

Front air conditioning system	341
Rear air conditioning system	355
Rear window and outside rear view mirror defoggers	363
Windshield wiper de-icer	364

3-3. Using the interior lights

Interior lights list	365
• Interior lights	366
• Personal lights	367

3-4. Using the storage features

List of storage features	369
• Glove box	371
• Coin holder	372
• Door pockets	372
• Cup holders	373
• Console box	374
• Non smokers boxes	376
• Auxiliary boxes	377

3-5. Other interior features

Sun visors	380
Vanity mirrors	381
Outside temperature display	382
Ashtrays	383
Cigarette lighters	384
Power outlets	386
Heated steering wheel	389
Climate control seats/seat heaters	391
Armrest	395
Retractable table	396
Rear sunshade	398
Rear door sunshades	401
Coat hooks	404
Floor mat	405
Trunk features	406
Garage door opener	408
Safety Connect	414

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior	422
Cleaning and protecting the vehicle interior	425

4-2. Maintenance

Maintenance requirements	428
General maintenance	430
Emission inspection and maintenance (I/M) programs	433

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions	434
Hood	437
Positioning a floor jack	438
Engine compartment	440
12-volt battery	452
Tires	456
Tire inflation pressure	465
Wheels	469
Air conditioning filter	471
Electronic key battery	474
Checking and replacing fuses	476
Headlight aim	482
Light bulbs	484

5 When trouble arises

5-1. Essential information

Emergency flashers	496
If your vehicle needs to be towed	497
If you think something is wrong	503

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	504
If a warning message is displayed	514
If you have a flat tire	517
If the hybrid system will not start	526
If the shift lever cannot be shifted from "P"	528
If the parking brake cannot be released	529
If the electronic key does not operate properly	531
If the 12-volt battery is discharged	535
If your vehicle overheats	539
If the vehicle becomes stuck	543
If your vehicle has to be stopped in an emergency	544

6

Vehicle specifications

6-1. Specifications

Maintenance data
 (fuel, oil level, etc.)..... 546

Fuel information..... 559

Tire information..... 562

6-2. Customization

Customizable features..... 573

7

For owners

Reporting safety defects
 for U.S. owners..... 584

Seat belt instructions
 for Canadian owners
 (in French)..... 585

SRS airbag instructions
 for Canadian owners
 (in French)..... 587

Index

Abbreviation list..... 598

Alphabetical index 600

What to do if...612

1

2

3

4

5

6

7